



HATOR® Arc 2 GAMING CHAIR

PACKAGE CONTENTS

A BACKREST	x1
B SEAT	x1
C SIDE COVERS KIT	x2
D ARMREST	x2
E GAS LIFT	x1
F GAS LIFT COVER	x1
G 5-BEAMS BASE	x1
H CASTERS	x5
I MAGNETIC HEAD CUSHION	x1
J ADJUSTABLE LUMBAR CUSHION	x1
K MULTIFUNCTIONAL MECHANISM	x1
L SCREW M8x25 mm	x16
M LARGE WASHER	x16
N GROVER	x16
O NOISELESS PADS	x4
P UNIVERSAL TOOL	x1
Q SPACER	x2

If you have problems during chair assembly, please contact us for further instructions.

8 Put the large washer (M) and grover (N) on the screw (L) as it is shown in the picture.



Do not attempt to adjust this lever until the backrest is installed. It will help you avoid the improper operation of the mechanism and injury to the hand.

IMPORTANT



4 Take the set of screws supplied with the chair



9 Install the backrest (A) and fix it with M8x25 mm screws (L) on the left and right sides. Start locking from the side of the backrest recline mechanism (right hinge). In case when the right magnetic cover holds not tight enough, please add 2 spacers (Q) under the mounting screws.



1 Remove all chair parts from the box without touching the backrest adjuster (the mechanism is on the seat). Before assembling, please check all parts by the checking list.



5 Fix the two armrests (D) to the seat base using M8x25 mm screws (L)




10 To get the full access to comfy usage magnet side covers (C), please remove the transportation screws from both sides. For further chair transportation please insert the screws back or take the covers off prior.



2



6 Fix the multifunctional mechanism (K) underneath the seat base using M8x25 mm screws (L). There should be noiseless soft pads (O) between the mechanism and the seat. Pay attention to the "FRONT" mark on the multi-block mechanism. The front of the mechanism should be facing forward.



11 Put the magnetic top covers (C) on both sides.



3 Place the assembled base on the floor and insert the gas lift (E) with the button up. Please put on the gas lift cover (F) on it.



7 Install the assembled seat on the gas lift (E). Ensure the gas lift fits securely into the hole in the multifunctional mechanism (K).



12 Place a magnetic head cushion (I) and lumbar support (J).



*Product and parts design are for reference only



BACKREST ADJUSTMENT

Fully pull the lever up and slowly recline the backrest backwards to the desired position. When the desired backrest angle is reached, slowly release the lever



3D ARMREST ADJUSTMENT

Press and hold the button to adjust the needed height. Rotate the armrest around the axis and move it forward or backward to find a comfortable position.



MULTI-BLOCK ADJUSTMENTS

The swing mode can be adjusted according to your weight. If a chair does not swing, turn the handle under the seat clockwise or counterclockwise, adjusting the swing stiffness to suit you. If the swing stiffness is adjusted correctly, you can swing easily in the chair.



CHANGING THE DISTANCE BETWEEN ARMRESTS

You can change the distance between the armrests. Loosen the M8 screw at the bottom of the armrest and move the armrest to the desired position, then tighten the screw in the selected position.



ADJUSTING THE SEAT HEIGHT AND ROLLING MODE

- To lower the seat height, turn the lever handle clockwise. To increase the seat height, stand up and turn the lever handle clockwise.
- To turn on the swing, pull the lever to the right. The chair will rock when you lean back.
- To turn off the rocking and lock the seat, align the seat in a horizontal position and push the lever to the left, towards the mechanism.

SWE Användarmanual
NO Brukermanual
NON Ingebruksmanual
AR دليل المستخدم
HE օգնական արկիչ

Lietotāja rokasgrāmata
Vantotojo vadovas
Käyttöohje
Kullanohje
TR Kullanıcı Kılavuzu
AR 說明書
FI Ohjekirja

Instrukcija obisklugu
Manual de utilizare
BR Manual de uso
BG Ръководство за употреба
CZ Uživateľský manuál
SK Používateľská príručka

User manual
Benutzerhandbuch
FR Manuel de l'utilisateur
IT Manuale d'uso
ES Manual de usuario
NL Handleiding

EN DE FR IT ES NL

IMPORTANT



Sit in the center of the seat, lean back on the backrest




Do not sit on the front edge of the chair



Do not step on a chair



Do not sit on the chair together



If the person is reclining in the chair, leaning back, do not move the chair




If the person is reclining in a chair, leaning back, do not overturn the chair



Do not shift the centre of gravity to the backrest



Do not insert your hand into the backrest adjustment mechanism



Do not sit with your clothes on. Avoid getting sweat on the upholstery of the chair

LIMITED WARRANTY TERMS

The manufacturer provides a 2-year limited warranty for all mechanical parts and components of the HATOR® Arc 2 XL gaming chairs.

IMPORTANT! The limited warranty does not apply to commercial use of the seat. Commercial use of the seats requires agreement with the supplier.

EN SAFETY GUIDELINES

- This chair is intended solely for its intended use.
- This chair is designed for one person use.
- To prevent the chair from tipping over:
- find the centre of gravity when backrests on the lumbar support;
- do not sit on the front edge of the seat;
- do not stand on the chair;
- do not press on the backrest when it is reclined.
- Use the product on a horizontal surface.
- When using on a hard floor, be sure to place a mat under the chair to avoid damaging the floor surface.
- When placing yourself in the chair, do so carefully to avoid applying excessive pressure to the gas lift cylinder, which could result in exceeding the set maximum load capacity.
- Move the chair carefully. While operating any function of the chair, always use smooth and controlled movements to ensure the safety of the product, humans and animals, as well as the surrounding environment.
- The armrests are designed solely to support your arms while you are seated properly in the chair. They are not intended to be used for sitting or any other unintended purpose.
- When fully reclining the backrest, it is strongly advised to keep both feet on the ground to prevent tipping or falling. Applying sudden or excessive force to the backrest could also cause the chair to tip over.
- Long periods at the computer and an uncomfortable position can cause discomfort and harm your health. Please try to take the most comfortable position and take timely breaks. If you experience severe discomfort or pain, stop using it immediately and consult a doctor.
- To avoid damaging the chair and causing an injury, be careful when moving it, please. Pay attention to the position of your hands when adjusting the
- movable elements and levers.
- When adjusting the chair's height by pulling the handle, avoid using excessive force.
- The chair is not created for usage in standard temperature conditions.
- Do not place the chair near heat sources to avoid surface damage and fire.
- To prevent damage and drying of PU leather, cracking of elastic components, do not put the chair near the radiator, fireplace, or other high-temperature sources and keep the chair out of direct sunlight.
- It is strictly forbidden to use the chair in places where flammable items are stored.
- For product safety, inspect all parts and functions every month.
- If any parts are loose, missing, or damaged, contact the reseller from whom you purchased the product. Do not use the chair until the issue is resolved.
- It is forbidden to knock out and disassemble the gas lift and other parts.
- Do not disassemble or interfere with the gas lift cylinder. Unauthorized tampering may result in explosive danger and injury.
- Do not use spare parts or accessories from third-party suppliers.
- Sit with your clothes on. Avoid getting sweat on the upholstery of the chair.
- While using the chair, avoid wearing clothing with rivets, sequins, or other sharp items that could damage the product and avoid clothing or materials that could cause discoloration of the chair.
- To prevent damage to the upholstery, keep the chair away from sharp objects, avoid rubbing against walls, furniture, and keep pets away.
- We recommend to wipe the chair after assembly in a hygienic purposes, please use an alcohol-free wipes or a special furniture cleaner according to its manual. Do not use aggressive detergents.
- Maximum recommended chair static load: 180 kg.

DE SICHERHEITSRICHTLIJNEN

- Dieser Stuhl ist ausschließlich für den vorgesehenen Gebrauch bestimmt. Dieser Stuhl ist für die Benutzung durch eine Person ausgelegt.
- Um ein Umkippen des Stuhls zu verhindern:
- finde dein Gleichgewichtszentrum, wenn die Rückenlehne auf die Lenkstange trifft;
- setze dich nicht auf die Vorderkante des Sitzes;
- drücke nicht auf die Rückenlehne, wenn sie zurückgelehnt ist.
- Verwenden Sie das Produkt auf einer waagrechten Oberfläche. Bewegen Sie den Stuhl vorsichtig. Während der Bedienung des Stuhls sollten Sie nur sanft und kontrollierte Bewegungen ausführen. Übermäßiger Druck auf den Gaszylinder zu vermeiden, der zur Überschreitung der maximalen Tragfähigkeit führen könnte.
- Bewegen Sie den Stuhl vorsichtig. Achten Sie bei der Bedienung jeder Funktion des Stuhls stets sanfte und kontrollierte Bewegungen, um die Sicherheit des Produkts, von Menschen und Tieren sowie der Umgebung zu gewährleisten.
- Die Armlehnen sind ausschließlich dafür ausgelegt, Ihre Arme zu stützen, während Sie richtig im Stuhl sitzen. Sie sind nicht dafür gedacht, darauf zu sitzen oder für andere nicht vorgesehene Zwecke verwendet zu werden. Beim vollständigen Zurücklehnen der Rückenlehne wird dringend empfohlen, beide Füße auf dem Boden zu halten, um ein Kippen oder Fallen zu verhindern. Das Anwenden von plötzlicher oder übermäßiger Kraft auf die Rückenlehne könnte auch das Umkippen des Stuhls verursachen.
- Langes Zeitalter am Computer und eine unbequeme Position können Unbehagen verursachen oder Ihren Gesundheitszustand verschlechtern. Bitte bewussten Position einzunehmen und rechtzeitig Pausen zu machen. Wenn Sie Beschwerden oder Schmerzen haben, hören Sie sofort auf, den Stuhl zu benutzen, und konsultieren Sie einen Arzt.
- Um Schäden am Stuhl und Verletzungen zu vermeiden, halten Sie den Stuhl von scharfen Gegenständen fern, vermeiden Sie Reibung an Wänden oder Möbeln und halten Sie Haustiere fern.
- Wir empfehlen, den Stuhl nach dem Zusammenbau zu hygienischen Zwecken zu reinigen. Verwenden Sie alkoholfreie Tücher oder einen speziellen Möbelschoner gemäß dessen Anleitung. Verwenden Sie keine aggressiven Reinigungsmittel.
- Die Stühle sind für die Verwendung unter normalen Temperaturbedingungen ausgelegt.
- Stellen Sie den Stuhl nicht in die Nähe von Wärmequellen, um Oberflächenschäden und Brandgefahr zu vermeiden.
- Um Schäden und Austrocknen des PU-Leders sowie Risse in Kunststoffteilen zu verhindern, stellen Sie den Stuhl nicht in die Nähe von Heizkörpern, Kaminen oder anderen Wärmequellen und vermeiden Sie direkte Sonneneinstrahlung.
- Es ist strengstens verboten, den Stuhl an Orten zu verwenden, an denen entzündliche Gegenstände gelagert werden oder in Räumen mit hoher Luftfeuchtigkeit.
- Zur Produktsicherheit überprüfen Sie alle Teile und Funktionen jeden Monat.
- Wenn Teile locker, fehlen oder beschädigt sind, wenden Sie sich an den Händler, von dem Sie das Produkt gekauft haben. Verwenden Sie den Stuhl nicht, bis das Problem behoben ist.
- Es ist verboten, den Gaslift und andere Teile auszuschießen und zu demontieren.
- Es ist verboten, Ersatzteile oder Zubehör von Drittanbietern zu verwenden, um Manipulationen am Stuhl vorzunehmen. Unbefugte Manipulationen können zu Explosionsgefahr und Verletzungen führen.
- Verwenden Sie keine Ersatzteile oder Zubehör von Drittanbietern.
- Sitzen Sie mit Ihrer Kleidung darauf, vermeiden Sie Schwelgen auf die Rückenlehne des Stuhls zu bekommen.
- Vermeiden Sie beim Benutzen des Stuhls Kleidung mit Nieten, Pfannkuchen oder anderen scharfen Gegenständen, die das Produkt beschädigen könnten, und vermeiden Sie Kleidung oder Materialien, die eine Verfärbung des Stuhls verursachen könnten.
- Um Schäden an der Rückenlehne zu vermeiden, halten Sie den Stuhl von scharfen Gegenständen fern, vermeiden Sie Reibung an Wänden oder Möbeln und halten Sie Haustiere fern.
- Wir empfehlen, den Stuhl nach dem Zusammenbau zu hygienischen Zwecken zu reinigen. Verwenden Sie alkoholfreie Tücher oder einen speziellen Möbelschoner gemäß dessen Anleitung. Verwenden Sie keine aggressiven Reinigungsmittel.
- Maximum recommended chair static load: 180 kg.

